

TITLE: Solara ion Reminder Note

Category: Solara ion

Document
Number: 08 - 4

Supplied by: Gerber Service

Last Modified: September 19, 2008

Summary: This weekly Solara ion Reminder Note contains two items:

- Correction to GerberCAT flush solution
- Working with 10 foot flat bed jobs

Correction to part number for GerberCAT flush solution

In the Reminder Note 08-1 the part number for the GerberCAT flush solution was incorrect. The correct part number is P82137B.

Working with 10 foot flat bed jobs

When using the flat bed feature, the Gerber Solara ion allows you to print up to 10' long. However, when printing materials in excess of 9', where the media comes to rest on the roll-to-roll platen, we highly recommend that you reinforce the platen portion of the vacuum by taping down the last foot of rigid material. This will keep materials from bowing at the roll-to-roll end and prevent the possibility of head strikes that could ruin the job or even worse your print heads.

For jobs shorter than 9', the material will rest fully on the table, therefore no tape is necessary. There are no extra precautions necessary when printing long jobs with the roll-to-roll portion of the printer.